

AEROCRAFT

MODELS

1/72 scale Phantom intakes for the Airfix kit

Cut the intake trunk as shown, and re-assemble as accurately and as smoothly as possible, note there is a small support / location lip. Cut the casting on the scribed line, as shown in the first picture. To ensure a good fit a small amount of filing maybe required as shown in the shaded area. Remove the small locating peg as the new resin part does not have the slot for this to locate within. As you will all know this is quite a complex area of the kit to get right and to assemble, so take care and dry fit the assembled intakes in the same manner as in the kit instructions. I found that a few areas on the kit parts benefit from a little scraping and sanding to assist in obtaining a good overall fit.

