



Your product shall have the following **contents**:

- four **3D printed fans**
- paint mask on **TAMIYA** sheet

**Instructions:**

1. Remove the outer railing which protects the fans using a resin saw or a side cutter.
2. Remove all 18 outer blade supports using a side cutter. Be careful not to break off blades.
3. Remove all 18 inner blade supports using a side cutter.
4. Remove the remaining three supports at the wheel hub assembly in the very center of the fan.
5. With the fan now detached from the support structure, turn it upside down and remove the burr.
6. Use CA glue (super glue) to attach the fan to part no. 42 of the Revell kit. You may need to shorten the Revell part a bit for a good fit.
7. When working with resin, it is important to apply a resin suitable primer and to prime the entire part. You can use the Revell part as a handle during painting.
8. Once the primer has dried, apply semi gloss black paint.
9. Apply the paint masks to each individual blade and cover the cone with masking tape.
10. Paint the leading edges using a titanium color.
11. Remove the paint masks, apply the spinner decal included in the Revell kit and you're **done!**

**Color recommendation:**

Color	Gunze	MRP	Revell Aqua	Tamiya
semi gloss black	92	005	302	XF01
Titanium	SM205	082	91	X32