

Check if the commander's cupola is installed correctly!
The middle viewing slit is located in the center!




Check the correct direction of the track links!



Check the correct direction of the track links!

Check if the commander's cupola is installed correctly!
The middle viewing slit is located in the center!



8
Bolts & Nuts for Idlers for each side!

