

48th Scale
NO.
48-56



F-14 TOMCATS # 1
MICROSCALE DECAL
BY KRASEL INDUSTRIES, INC. SANTA ANA, CA 92705

AIRCRAFT
'2.50



48th Scale
NO.
48-56



F-14 TOMCATS # 1
MICROSCALE DECAL
BY KRASEL INDUSTRIES, INC. SANTA ANA, CA 92705

AIRCRAFT
'2.50

Recommended Kit - Fujimi F-14A 1/48th



GENERAL PAINTING NOTES:

Cockpit Interior: Dark Green FS 36231

This includes floor, bulkheads, side panels, instrument panels, seat frames and canopy inside bracing.

Ejection Seat:

Dark Gull Gray FS 36231: seat frame

Dark Green FS 34079: Parachute rack and seat cushion.

Black FS 17038: Headrest and seat rails

Yellow FS 33538: Face curtain handles (note - face curtain handles have Black stripes)

Wheel Wells, Door Insides and Wheel Struts:

Gloss White FS 27875: Interior of wheel wells, inside of gear doors, wheel struts, wheel hubs, interior of engine intakes and access panels.

Gloss Insignia Red FS 31136: Edges on all landing gear doors

Natural Metal: Oleo struts, lips on intakes and panel in front of gun.

The F-14 uses a 25" insignia.

References:

F-14 Tomcat in Action # 32
Squadron Signal Publications

Kuko Fan Famous Aircraft Series # 83 and # 89.

Grumman F-14
J.P. Stevenson
Aero Series # 25


The MICRO SCALE DECAL SYSTEM

1. Surface to be decalced must have a smooth, glossy, painted finish. (Do not apply decals to unpainted surfaces or they will not adhere.) To obtain this surface either paint the model with glossy paints or spray MICRO GLOSS over matte finish paint. IMPORTANT: Spray MICRO GLOSS over entire model or uneven patches will appear when the flat finish is added later. Allow paint to dry thoroughly.
2. For best results, surface to be decalced should be horizontal. A small vise is helpful here, or a box can be made into a jig to allow the model to lay on its side.
3. Cut each decal subject from the sheet only as needed. DO NOT cut clear film away from design. Using tweezers, dip decal completely into water then remove and allow decal adhesive to soften. About one minute should be sufficient.
4. While adhesive is softening use a soft, medium-size brush, a No. 7 red table water color brush is ideal, and wet the area to be decalced with a few drops of MICRO SET (Blue label). This contains a wetting agent and helps eliminate tiny air bubbles.
5. Holding the decal paper with tweezers, use the brush to slide the loosened decal into the MICRO SET on the model.

6. Now place a few drops of MICRO SOL (Red label) directly onto the decal and position the decal exactly where it is to remain.
7. The MICRO SOL will soften the decal and allow it to conform exactly to the surface beneath. DURING THIS PROCESS THE DECAL WILL WRINKLE AND DISTORT. DO NOT TOUCH IT! THIS IS NATURAL AND AN IMPORTANT PART OF THE SYSTEM! As the decal dries it will flatten-out and lay down. When finally dry there will be no distortion and the decal will be permanently bonded to the paint beneath. Actual drying time will vary according to temperature and humidity.
8. When decal is dry, examine it for any air bubbles. If any are found, puncture them with a sharp needle and put a drop of MICRO SOL over the bubble and allow to dry.
9. Carefully examine the clear film to be sure no shivering has appeared. If any is present, puncture the film several times with a sharp needle and apply MICRO SOL. The shivering should vanish as the SOL touches it.
10. After the decals have dried for several hours, carefully wash the decal adhesive from the entire model.
11. After the decals have dried for at least 12 hours, complete the model by spraying with either MICRO FLAT or MICRO GLOSS, depending on the sheen desired on the finished model.



The International Plastic Modelers Society is an organization devoted to developing the plastic modeling art. It was formed "By Modelers - For Modelers". If you wish to expand your modeling talents, write for further information to: IPMS/USA, New Member Information, P.O. Box 2555, Long Beach, Ca., 90801;



NOTE-wing overlap area is a darker color than FS 36440. Deepen your color to FS 36373.

